




Installation Instructions for
**Solar Light 270mm Round
 TILE ROOF**




Decide on a roof location that will expose the Solar Panel to as much sunlight as possible.




Space & attach brackets to Solar Panel so they align with the peak of Corrugations.



Attach brackets to the roof with screws. Seal under the screws. Run cable under ridge cap and into roof cavity.



Trace Light Diffuser onto ceiling location and cut out using jigsaw or plaster knife.




Connect cable to Light Diffuser and mount Light Diffuser to ceiling using spring clips.


Installation Instructions for
**Solar Light 270mm Round
 CORRUGATED IRON ROOF**




Decide on a roof location that will expose the Solar Panel to as much sunlight as possible.




Space & attach brackets to Solar Panel so they align with the peak of Corrugations.



Attach brackets to the roof with screws. Seal under the screws. Run cable under ridge cap and into roof cavity.



Trace Light Diffuser onto ceiling location and cut out using jigsaw or plaster knife.



Connect cable to Light Diffuser and mount Light Diffuser to ceiling using spring clips.